



basicCAN 61 PLUS

USB Controller

User Manual

(Translation of Original docu)

Document Version 1.5



GOPEL electronic GmbH

Goeschwitzer Str. 58/60 • D-07745 Jena

+ 49-3641-6896-597 • ats_support@goepel.com • www.goepel.com

© 2015 GOEPEL electronic GmbH. Alle Rechte vorbehalten. All rights reserved.

The software described in this manual as well as the manual itself are supplied under license and may be used or copied only in accordance with the terms of the license.
The customer may make one copy of the software for safety purposes.

The contents of the manual is subject to change without prior notice and is supplied for information only.

The hardware and software might be modified also without prior notice due to technical progress.

In case of inaccuracies or errors appearing in this manual, GOEPEL electronic GmbH assumes no liability or responsibility.

Without the prior written permission of GOEPEL electronic GmbH, no part of this documentation may be transmitted, reproduced or stored in a retrieval system in any form or by any means as well as translated into other languages (except as permitted by the license).

GOEPEL electronic GmbH is neither liable for direct damages nor consequential damages from the company's product applications.

Printed: 09.01.2015

All product and company names appearing in this manual are trade names or registered trade names of their respective owners.

Issue: January 2015

1	NOTES ON THE EC DECLARATION OF CONFORMITY	1-1
2	INSTALLATION	2-3
2.1	HARDWARE INSTALLATION	2-3
2.2	DRIVER INSTALLATION	2-3
2.2.1	USB	2-3
2.2.2	Ethernet	2-5
3	HARDWARE	3-1
3.1	DEFINITION	3-1
3.2	TECHNICAL DATA	3-2
3.2.1	Dimensions	3-2
3.2.2	Basic Characteristics	3-2
3.3	FRONT VIEW	3-3
3.4	REAR VIEW	3-4
3.5	FUNCTION	3-4
3.5.1	Status LEDs	3-4
3.5.2	Supply of basicCAN 61 PLUS	3-5
3.5.3	Test object Supply	3-5
3.5.4	OnBoard Interfaces	3-6
3.5.5	FlexRay Extension board	3-7
3.5.6	CAN Extension board	3-8
3.5.7	Digital IO	3-9
3.5.8	IO Extension	3-11
3.5.9	Addressing	3-17
3.5.10	Isolation	3-17
3.5.11	Connector Pinout	3-18
3.6	PRODUCT INFORMATION	3-21
4	SOFTWARE	4-1
4.1	G-API PROGRAMMING	4-2
4.2	USERCODE PROGRAMMING	4-3

1 Notes on the EC Declaration of Conformity

**GOPEL electronic GmbH
Goeschwitzer Straße 58-60
D-07745 Jena**

With the EC Declaration of Conformity we declare the compliance of the GOPEL electronic GmbH product described in this Manual with the requirements of the Directive 2006/95/EG – Low Voltage Directive and with the Directive 2004/108/EG about the Electromagnetic Compatibility. Any modification to the product, not authorized by us, will invalidate the corresponding declaration.

The product is marked with the symbol



2 Installation

2.1 Hardware Installation



We recommend to install/ update the driver software before connecting the device to the PC/ Laptop (see [Driver Installation/ USB](#) chapter).

As a rule hardware installation for basicCAN 61 PLUS means to connect the power supply cable and the USB or Ethernet cable to the control PC.



Please use the supplied USB cable to connect the basicCAN 61 PLUS stand-alone device to the PC's USB interface.
Other cables may be inapplicable.

2.2 Driver Installation

- 2.2.1 USB To install the GOEPEL electronic USB drivers on your system, execute the G-USB driver setup.
For this, start the *G-USB-Setup-*.exe* setup program (the asterisk stands for the version number) of the delivered CD and follow the instructions.



Your basicCAN 61 PLUS can be operated under Windows® XP as well as under Windows® 7/ 32 bit and Windows® 7/ 64 bit.

Before connecting the basicCAN 61 PLUS stand-alone hardware to a USB port of your PC, please ensure that the external power supply of the device is ready for operation (the hardware of basicCAN 61 PLUS is NOT supplied via USB). Then, connect the device by the supplied USB cable to a USB port of your PC.

Due to the plug and play capability of Windows®, the operating system will recognize the device automatically. As soon as it has been detected, the Windows® "Hardware wizard" will start and guide you through the device driver installation process.

Select the "Install software automatically" option and click "Next" to continue.

On completion of the installation process, Windows® will request you to reboot your computer.
For safe and reliable operation this step is strongly recommended.

After the installation, you can check whether the unit is properly embedded by the system.

As an example, the following figure shows the successful embedding of four basicCAN 61 PLUS devices (each device appears as USB 6153 in the Device Manager):



Figure 2-1:
basicCAN 61 PLUS Installed



Please note that the Device Manager shows ALL USB controllers supported by this driver.

2.2.2 Ethernet

If the Ethernet interface is used for communication with the control PC, there is no driver installation required.

After the [Hardware Installation](#), the device can directly be addressed via the IP Address (see also [Addressing](#)).

This IP Address can be changed by the HardwareExplorer. The newly set IP Address becomes effective after a restart.




Figure 2-2: IP Address in the GOEPEL electronic HardwareExplorer

3 Hardware

3.1 Definition

The basicCAN 61 PLUS stand-alone device of GOPEL electronic GmbH, based on the corresponding USB 6153 USB/ Ethernet board, should be connected to a PC or laptop. It was developed for applications out of complex test systems.

The external power supply of 7-25 VDC allows the use of this device for data acquisition and the inspection of signals for a multitude of applications, e.g. in motor vehicles.

basicCAN 61 PLUS provides the following resources:

- 2 basic CAN interfaces
(4 CAN interfaces with optional CAN Extension board)
(see [OnBoard Interfaces](#))
- optionally 2 further CAN/ LIN or K-Line interfaces onboard
(see [OnBoard Interfaces](#))
- optionally 2 FlexRay nodes with 2 channels each
(see [FlexRay Extension board](#))
- 4 digital input and output channels with TTL level onboard
(see [Digital IO](#))
- optionally 4 additional digital inputs and 4 outputs
with extended voltage range (see [IO Extension](#))
- optionally 4 resp. 6 analog input and output channels
(see [IO Extension](#))
- 600MHz Power PC with 512MB RAM, 256MB Flash
- Communication interfaces and IO channels
are galvanically separated from the user interface
- High flexibility through pluggable transceiver modules and
possible variants of the IO Extension Board
- Control of the device via USB 2.0 or Ethernet
(see [Addressing](#) and [Ethernet](#))
- 1 Gbit Ethernet interface at the device's rear side also useable
as volume data and debug interface
- 11 front panel LEDs for status indication (see [Status LEDs](#))

The following figure shows a basicCAN 61 PLUS:



Figure 3-1:
basicCAN 61 PLUS

3.2 Technical Data

3.2.1 Dimensions The basicCAN 61 PLUS has the following dimensions:
 - 230 mm x 169 mm x 82 mm (L x W x H)

3.2.2 Basic Characteristics A basicCAN 61 PLUS has the following basic characteristics:

Indication	Min.	Typ.	Max.	Unit	Remarks
CAN/ LIN or K-Line interfaces		2	4		See OnBoard Interfaces
CAN Extension			2		See OnBoard Interfaces
FlexRay Extension			2		See FlexRay Extension board
IO Resources Extension			1		See IO Extension

3.3 Front View



Figure 3-2:
Front view

- Node A FlexRay node 1 (optionally)
- , Node B FlexRay node 2 (optionally), or CAN 5, 6 (optionally)
- ☒ Status 1, 2, 3, 4 Status LEDs 1..4
- DO 1, 2, 3, 4 State of Digital outputs 1..4
- Ž Power 1, 2, 3 Power LEDs
- f Node 1 CAN 1
- „ Node 2 CAN 2
- ... Node 3 CAN 3 (optionally, also LIN or K-Line possible)
- † Node 4 CAN 4 (optionally, also LIN or K-Line possible)
- ‡ Analog Analog E/ A 1..4 (or ..6, optionally)
- ^ Digital Digital-E/ A 1..4 (optionally ..8)
- %₀₀ KL30 (red) KL15 (yellow) KL31 (black) Outputs for test object supply

3.4 Rear View



Figure 3-3: Rear view

- Ethernet Ethernet connection
- , USB USB 2.0 connection
- f* ext. Power basicCAN External supply input for basicCAN 61 PLUS
- ” ext. Power Front External supply input for Test object
(red - plus, black - minus)

3.5 Function

3.5.1 Status LEDs

The LEDs arranged at the front panel (see Figure 3-2) indicate several states of your basicCAN 61 PLUS:

Status 1, 2, 3, 4 Status LEDs: These LEDs indicate the current operation state of the basicCAN 61 PLUS

The operation states are explained in the following table:

LED 1	LED 2	LED 3	LED 4	Remarks
Permanently ON				Controller does not run (error!)
Alternately blinking				Bootloader software runs
	blinking			Firmware runs
ON (shortly)				State during execution of a Firmware command on the OnBoard interfaces 1..4
			ON	Ethernet connection established

DO 1..4 Digital OUT: These LEDs indicate the state of the digital outputs 1..4 (Digital connector)

Power LEDs 1..3: The two upper LEDs indicate that the KL30 test object supply is connected, while the lower LED indicates that the KL15 test object supply is switched ON


3.5.2 Supply of basicCAN 61 PLUS

For operating the basicCAN 61 PLUS, there is an external power supply of 7..25 VDC required. For this, you can use the ext. Power basicCAN connector for the delivered AC adaptor plug (12 VDC) at the device's rear side, with coaxial power plug (2.1 x 5.5 mm/ plus polarity inside).

3.5.3 Test object Supply

To supply the test object, a voltage connected to the ext.Power Front connection at the device's rear side is distributed to the KL30, KL15, KL31 sockets at the front panel.

The KL15 voltage can be switched by software by means of the Digital OUT1 digital output (G-API command G_lo_Outputs_Digital_Set):



*Figure 3-4:
Test object Supply Internal*

3.5.4 OnBoard Interfaces

The basicCAN 61 PLUS has two (optionally up to six) Communication interfaces, designed as CAN 2.0B interfaces using the TJA1041A Highspeed CAN Transceiver.

Optionally it is possible to plug in different/ further transceivers (totally 4, that means not for the CAN Extension board).

By the type of the plugged-in transceivers you decide the performance of the assigned interfaces!



For changing or plugging in additional transceivers, open the stand-alone device (with the system **switched off**).

To do that, unscrew and remove the four upper screws of the frontal and rear plates, and unscrew slightly the four lower screws (until the upper cover can be removed). Please proceed extremely carefully, otherwise the device could be damaged.

When plugging in transceivers, please attend to their correct position and orientation.

In the case of further inquiries, please contact our support department (ats_support@goepel.com).

The position and orientation of the transceivers can be seen in the following figure:




Figure 3-5:
Transceiver positions

Each transceiver type is coded and can be identified clearly. For the available types of transceivers, see [Product Information](#).

As a rule all four interfaces are supplied by an internal voltage of 12V ($UBAT_{int}$) generated from ext. Power Supply (see Figure 3-3).

In case of using other voltages for the interfaces, this internal voltage can be switched off individually by software (G-API commands

`G_Can_Node_InternalVBat_Disable`
`G_Lin_Node_InternalVBat_Disable` or
`G_KLine_Node_InternalVBat_Disable`).

Then, an external voltage ($UBAT_{ext}$) must be supplied via the predefined pins of the corresponding frontal connector Node 1..4.

In case the internal power supply has to be used again later, execute the G-API commands

`G_Can_Node_InternalVBat_Enable`
`G_Lin_Node_InternalVBat_Enable` or
`G_Kline_Node_InternalVBat_Enable`.

3.5.5 FlexRay Extension board

The basicCAN 61 PLUS board has two extension sockets at its top side to plug in FlexRay Extension boards. Each board has an independent FlexRay controller and two FlexRay transceivers, providing full dual channel functionality.



For a basicCAN 61 PLUS with CAN Extension board, only one FlexRay Extension board can be plugged in.

A basicCAN 61 PLUS FlexRay Extension board provides the following features:

- FlexRay controller (Freescale MFR4310)
- FlexRay 2.1 protocol compliant
- Support of the following FlexRay transmission rates (in Mbit/s):
10 | 8 | 5 | 2.5
- 2 FlexRay Transceivers (TJA 1080)
- Wakeup detection
- Switchable termination resistors
- Full galvanic isolation
- Isolated power supply of the transceivers

The following table shows the main characteristics of a FlexRay module:

Symbol	Indication	Min.	Typ.	Max.	Unit	Remarks
FlexRay interface						
	Transmission rate	2.5		10	Mbit/s	Per channel
R _{FR}	Termination resistor		100		Ω	detachable



Notes on R_{FR}:

The 100Ω bus termination resistor can be deactivated by software (G-API command G_FlexRay_Node_BusTermination_Disable, reactivation by G_FlexRay_Node_BusTermination_Enable).

When configured with two FlexRay modules, both FlexRay modules can be used jointly to startup a FlexRay cluster.

In this case one node will be the leading cold starter and the other one the following cold starter.



In cases where the ECU under test is a cold start node itself, a single module can start up the cluster.

This way the second module could be used to operate a second FlexRay cluster independently.

3.5.6 CAN Extension board

In the case there are more CAN interfaces required, a CAN Extension board for two CAN interfaces can be plugged to the position for FlexRay Node B (generally providing CAN5 and CAN6).

The highspeed transceivers TJA1041A for these two interfaces can not be exchanged by other transceiver types.

Moreover, no external supply by $UBAT_{ext}$ is possible, the supply voltage comes from $UBAT_{int}$ (12V).

The termination resistor for both transceivers is switchable.

Symbol	Indication	Min.	Typ.	Max.	Unit	Remarks
CAN V2.0B Interfaces Node 1..2 (optionally ..4)						
	Transmission rate			1	Mbit/s	
$UBAT_{int}$	Internal battery voltage		12		V	detachable
$UBAT_{ext}$	External battery voltage			27	V	
R_{CAN}	Termination high-speed transceiver		120		Ω	detachable
R_{CAN}	Termination low-speed transceiver			10	k Ω	R_{CAN}
CAN V2.0B Interfaces Node 5..6 (optionally)						
	Transmission rate			1	Mbit/s	
$UBAT_{int}$	Internal battery voltage		12		V	
R_{CAN}	Termination high-speed transceiver		120		Ω	detachable
LIN V2.1 Interfaces Node 3..4 (optionally)						
	Transmission rate			19.2	kbit/s	
$UBAT_{int}$	Internal battery voltage		12		V	detachable
$UBAT_{ext}$	External battery voltage			27	V	
R_{LIN}	Pullup resistor	1	30		k Ω	switchable Master/ Slave
K-Line Interfaces Node 3..4 (optionally)						
	Transmission rate			9.6	kbit/s	
$UBAT_{ext}$	External battery voltage		12	27	V	



Notes on R_{CAN} for the high-speed Transceiver:

The 120 Ω Bus termination resistor can be deactivated by software (G-API command `G_CAN_Node_BusTermination_Disable`, reactivation by `G_CAN_Node_BusTermination_Enable`).



Notes on R_{LIN} : The 1k Ω pullup resistor corresponds to the LIN Master bus termination, it can be activated by software (G-API command `G_Lin_PullUpResistor_Enable` à Master, deactivation by `G_Lin_PullUpResistor_Disable` à Slave).

In the deactivated state, the internal termination resistance of the LIN transceiver is effective (typical 30k Ω for TJA1020).

3.5.7 Digital IO All in all your basicCAN 61 PLUS has up to 8 digital inputs and outputs. The 1..4 onboard inputs and outputs respectively have the following parameters:

Symbol	Indication	Min.	Typ.	Max.	Unit	Remarks
Digital inputs 1..4 (onboard)						
U_{IH}	High-level input voltage	3.5		5.5	V	
U_{IL}	Low-level input voltage			1.5	V	
I_L	Input leakage current			35	μ A	
Digital outputs 1..4 (onboard)						
U_{OH}	High-level output voltage	3.8		4.3	V	DIGITAL_OUT1 already assigned to switch KL.15
U_{OL}	Low-level output voltage			0.5	V	
I_{OUT}	Output current			4	mA	




Figure 3-6: Circuit diagram extract of onboard Digital Inputs 1..4




Figure 3-7: Circuit diagram extract of onboard Digital outputs 1..4

3.5.8 IO Extension

Additional analog and digital inputs and outputs as well as various interfaces become available by plugging in an extension board. GOPEL electronic GmbH offers two different types: Type 1 and Type 2.

The Type 1 IO Extension board has additional resources as follows:

Symbol	Indication	Min.	Typ.	Max.	Unit	Remarks
Digital inputs 5..8						
N	Number of inputs			4		
U _{IH}	High-level input voltage	3.5		25	V	
U _{IL}	Low-level input voltage			3.0	V	
I _L	Input current			1,8	mA	
Digital outputs 5..8						
N	Number of outputs			4		
U _{OH}	High-level output voltage	4.8		5	V	
U _{OL}	Low-level output voltage			0.5	V	
I _{OUT}	Output current			8	mA	
Analog inputs						
N	Number of inputs			6		
U _{IN}	Input voltage	0		10	V	
	Resolution			10	bit	
Analog outputs						
N	Number of outputs			6		
U _{OUT}	Output voltage	0		10	V	
	Resolution			10	bit	




Figure 3-8: Circuit diagram extract of Digital inputs 5..8 for IO Extension board Type 1




Figure 3-9: Circuit diagram extract of Digital outputs 5..8 for IO Extension board Type 1




Figure 3-10: Circuit diagram extract of Analog inputs 1..6 for IO Extension board Type 1




Figure 3-11: Circuit diagram extract of Analog outputs 1..6 for IO Extension board Type 1

The Type 2 IO Extension board has additional resources as follows:

Symbol	Indication	Min.	Typ.	Max.	Unit	Remarks
Digital inputs 5..8						
N	Number of inputs			4		
U _{IH}	High-level input voltage	3.5		25	V	
U _{IL}	Low-level input voltage			3.0	V	
I _L	Input current			1.8	mA	
Digital outputs 5..8						
N	Number of outputs			4		
U _{OH}	High-level output voltage			25	V	Supply via pin UEXT _{IO}
U _{OL}	Low-level output voltage		open		V	Integrated recovery diode
I _{OUT}	Output current			200	mA	
Analog inputs						
N	Number of inputs			4		
U _{IN}	Input voltage			25	V	
	Resolution			10	bit	
R _L	Input resistance		125		kΩ	
Analog outputs						
N	Number of outputs			4		
U _{OUT}	Output voltage			25	V	Supply via pin UEXT _{IO}
I _{OUT}	Output current per channel			10	mA	
	Resolution			10	bit	
External IO Voltage input U _{EXT_IO}						
UEXT _{IO}	External IO Voltage	7		26	V	




Figure 3-12: Circuit diagram extract of Digital inputs 5..8 for IO Extension board Type 2




Figure 3-13: Circuit diagram extract of Digital outputs 5..8 for IO Extension board Type 2




Figure 3-14: Circuit diagram extract of Analog Inputs 1..4 for IO Extension board Type 2




Figure 3-15: Circuit diagram extract of Analog outputs 1..4 for IO Extension board Type 2

3.5.9 Addressing

basicCAN 61 PLUS units provide a 1Gbit Ethernet interface and a USB 2.0 interface. Both interfaces can be used for the communication of the unit with the host PC.

In case of using the Ethernet interface, the device can be controlled via the default IP Address 192.168.1.62, Port 5134, which can be changed if required. In principle, there are two ways for this:

- HardwareExplorer: Select the device, under Device set the required IP Address;
the new IP Address is effective after restart
- G API Command G_Common_Ethernet_IpAddress_Set;
the new IP Address is effective after restart

Addressing of basicCON 61 PLUS devices controlled via the USB interface takes place exclusively according to their serial numbers: The device with the least serial number is always the device with the number 1.



To improve clarity, we recommend to connect several basicCAN 61 PLUS devices (if applicable) in the order of ascending serial numbers to the PC/ Laptop.

3.5.10 Isolation

Electric surges can harm expensive test equipment and may lead to unreliable test results. Electric isolation protects against electric surges and can help to suppress dangerous electrical transients. It also eliminates ground loops, responsible for data errors due to ground potential differences.

A basicCAN 61 PLUS unit provides electric isolation between the USB/ Ethernet system and all input and output signals of the frontal connectors. This includes the CAN, LIN, K-Line and FlexRay communication interfaces as well as digital and analog IOs.

3.5.11 Connector Pinout

The following table shows the pinout of the CAN frontal connectors Node 1..2 (optionally ..4) (type D-SUB 9poles female):

Pin	Signal	Pin	Signal
1	R _{low} -CAN_L	6	Not used
2	CAN_L	7	CAN_H
3	GND _{ISO}	8	R _{low} -CAN_H
4	Not used	9	UBAT _{ext}
5	Not used		

The following table shows the pinout of the CAN frontal connector Node B (optionally assigned, type D-SUB 9poles female):

Pin	Signal	Pin	Signal
1	Not used	6	Not used
2	CAN5_L	7	CAN5_H
3	GND _{ISO}	8	CAN6_H
4	CAN6_L	9	Not used
5	Not used		

The following table shows the pinout of the LIN frontal connectors Node 3..4 (optionally assigned, type D-SUB 9poles female):

Pin	Signal	Pin	Signal
1	Not used	6	Not used
2	Not used	7	LIN
3	GND _{ISO}	8	Not used
4	Not used	9	UBAT _{ext}
5	Not used		

The following table shows the pinout of the K-Line frontal connectors Node 3..4 (optionally assigned, type D-SUB 9poles female):

Pin	Signal	Pin	Signal
1	Not used	6	Not used
2	L-Line	7	K-Line
3	GND _{ISO}	8	Not used
4	Not used	9	UBAT _{ext}
5	Not used		



The UBAT_{ext} potentials on the Node 1..4 connectors are not interconnected internally. If required, an external voltage can be supplied for each of these connectors (before, the internal voltage must be switched off, see [OnBoard Interfaces](#)).

The following table shows the pinout of the FlexRay frontal connectors Node A/ B (optionally assigned, type D-SUB 9poles female):

Pin	Signal	Pin	Signal
1	Not used	6	Not used
2	FlexRayA_BM	7	FlexRayA_BP
3	GND _{ISO}	8	FlexRayB_BP
4	FlexRayB_BM	9	Not used
5	Not used		

The following table shows the pinout of the Analog frontal connector for IO Extension Type1 (optionally assigned, type D-SUB 15poles female):

Pin	Signal	Pin	Signal
1	ANALOG_IN1	9	ANALOG_IN2
2	ANALOG_IN3	10	ANALOG_IN4
3	ANALOG_IN5	11	ANALOG_IN6
4	GND _{ISO}	12	ANALOG_OUT1
5	ANALOG_OUT2	13	ANALOG_OUT3
6	ANALOG_OUT4	14	ANALOG_OUT5
7	ANALOG_OUT6	15	UEXT _{IO}
8	GND _{ISO}		

The following table shows the pinout of the Analog frontal connector for IO Extension Type2 (optionally assigned, type D-SUB 15poles female):

Pin	Signal	Pin	Signal
1	ANALOG_IN1	9	ANALOG_IN2
2	ANALOG_IN3	10	ANALOG_IN4
3	Not used	11	Not used
4	GND _{ISO}	12	ANALOG_OUT1
5	ANALOG_OUT2	13	ANALOG_OUT3
6	ANALOG_OUT4	14	Not used
7	Not used	15	UEXT _{IO}
8	GND _{ISO}		

The following table shows the pinout of the Digital frontal connector for IO Extension Type1 (partly optionally assigned, type D-SUB 25poles female):

Pin	Signal	Pin	Signal
1	DIGITAL_IN1	14	DIGITAL_IN2
2	DIGITAL_IN3	15	DIGITAL_IN4
3	DIGITAL_IN5	16	DIGITAL_IN6
4	DIGITAL_IN7	17	DIGITAL_IN8
5	GND_{ISO}	18	DIGITAL_OUT1
6	DIGITAL_OUT2	19	DIGITAL_OUT3
7	DIGITAL_OUT4	20	DIGITAL_OUT5
8	DIGITAL_OUT6	21	DIGITAL_OUT7
9	DIGITAL_OUT8	22	GND_{ISO}
10	Not used	23	Not used
11	Not used	24	Not used
12	GND_{ISO}	25	UEXT _{IO}
13	GND_{ISO}		



The pinout of the Digital connector when the IO Extension is not mounted is indicated by **bold** characters.

The following table shows the pinout of the Digital frontal connector for IO Extension Type2 (partly optionally assigned, type D-SUB 25poles female):

Pin	Signal	Pin	Signal
1	DIGITAL_IN1	14	DIGITAL_IN2
2	DIGITAL_IN3	15	DIGITAL_IN4
3	DIGITAL_IN5	16	DIGITAL_IN6
4	DIGITAL_IN7	17	DIGITAL_IN8
5	GND_{ISO}	18	DIGITAL_OUT1
6	DIGITAL_OUT2	19	DIGITAL_OUT3
7	DIGITAL_OUT4	20	DIGITAL_OUT5
8	DIGITAL_OUT6	21	DIGITAL_OUT7
9	DIGITAL_OUT8	22	GND_{ISO}
10	Do not connect!	23	Do not connect!
11	Do not connect!	24	Do not connect!
12	GND_{ISO}	25	UEXT _{IO}
13	GND_{ISO}		



The pinout of the Digital connector when the IO Extension is not mounted is indicated by **bold** characters.



The GND_{ISO} potentials of the Node 1..4, Node A/ B, Analog and Digital connectors are internally interconnected.

3.6 Product Information

basicCAN 61 PLUS is an intelligent, programmable CAN Controller designed as a stand-alone device with two CAN interfaces in its basic version.

It can be combined with a multitude of options.

Here is a list of available variants and options:

basicCAN 61 PLUS CAN Controller for Windows XP/ Windows 7	
	Basic variant: CAN Controller with 2 CAN nodes and 2 CAN Transceiver modules as well as 4 digital inputs and 4 digital outputs (all onboard)

Options for basicCAN 61 PLUS	
CAN node	Additional CAN node for basicCAN 61 PLUS devices onboard to upgrade on 3 or 4 communication nodes, incl. transceiver module(s) Note: The total quantity of installable CAN/ LIN/ K-Line nodes at the same time amounts 4 per basicCAN 61 PLUS device without CAN Extension board
CAN Extension board	Additional board with 2 further CAN nodes to upgrade on 6 CAN nodes, incl. transceiver modules Note: Total quantity of installable CAN Extension boards at the same time amounts 1 per basicCAN 61 PLUS device
LIN node	Additional LIN node for basicCAN 61 PLUS devices onboard to upgrade on 3 or 4 communication nodes, incl. transceiver module(s) Note: Total quantity of installable CAN/ LIN/ K-Line nodes at the same time amounts 4 per basicCAN 61 PLUS device without CAN Extension board
K-Line node	Additional K-Line node for basicCAN 61 PLUS devices onboard to upgrade on 3 or 4 communication nodes, incl. transceiver module(s) Note: The total quantity of installable CAN/ LIN/ K-Line nodes at the same time amounts 4 per basicCAN 61 PLUS device without CAN Extension board
FlexRay node	Additional FlexRay node for basicCAN 61 PLUS devices incl. 2-channel FlexRay module, FlexRay controller MFR 4310 with 2 transceivers of TJA 1080 type (at FlexRay Extension board) Note: The total quantity of installable FlexRay nodes at the same time amounts 2 per basicCAN 61 PLUS device (1 if the CAN Extension Board is installed); This option is useable independent from and additional to options CAN/ LIN/ K-Line nodes and IO Extension board

Options for basicCAN 61 PLUS	
IO Extension board Type 1	General Input/ Output Module for basicCAN 61 PLUS devices incl. 6 analog Inputs and 6 analog Outputs, 4 digital Inputs and 4 digital Outputs Note: The total quantity of installable IO Extension boards at the same time amounts 1 per device; this option is useable independent from and additional to options CAN/ LIN/ K-Line and FlexRay nodes
IO Extension board Type 2	General Input/ Output Module for basicCAN 61 PLUS devices incl. 4 analog Inputs and 4 analog Outputs, 4 digital Inputs and 4 digital Outputs Note: The total quantity of installable IO Extension boards at the same time amounts 1 per device; this option is useable independent from and additional to options CAN/ LIN/ K-Line and FlexRay nodes

For the continuation of this table please see next page.

Options for basicCAN 61 PLUS	
CAN TJA1054	CAN low speed transceiver module type TJA1054
CAN TJA1041A	CAN high speed transceiver module type TJA1041A
CAN NCV7356D1G	CAN single wire transceiver module type NCV7356D1G
LIN TJA1020	LIN transceiver module type TJA1020
LIN TJA1020 Iso	LIN transceiver module type TJA1020 isolated channel selective
LIN TLE7259G	LIN transceiver module type TLE7259G
K-Line L9637D	K-Line transceiver module type L9637D
K-Line L9637D Iso	K-Line transceiver module type L9637D isolated channel selective
RS232 TRSF3221E	RS232 transceiver module type TRSF3221E
DIAG KW2000 TP1.6	Keyword 2000 on TP1.6 on-board CAN Diagnostic software
DIAG KW2000 TP2.0	Keyword 2000 on TP2.0 on-board CAN Diagnostic software
DIAG KW2000 ISO-TP	Keyword 2000 on CAN-ISO-TP on-board CAN Diagnostic software
DIAG UDS ISO-TP	UDS on CAN-ISO-TP on board CAN Diagnostic software
DIAG GMLan	GMLan on-board CAN Diagnostic software
DIAG J1939	J1939 on-board CAN Diagnostic software
CAL CCP2.1	CAN Calibration Protocol CCP2.1
LIN adv-lib	Advanced library for Test of the LIN protocol specific. 2.0/ 2.1
Net2Run	<p>Software tool to generate signal based Rest bus Simulation(s) in heterogeneous car networks.</p> <p>This software solution is based on the AUTOSAR approach. Direct signal access (reading and manipulation) is provided via G-API functions.</p> <p>Further Net2Run features a gateway routing editor with PDU and signal mapping functionality.</p> <p>Net2Run supports the automatic import of bord net data in the *.dbc, *.ldf and Fibex formats.</p>
Net2Run Runtime	<p>Runtime module for executing the rest bus simulation files (*.rbs files) created by Net2Run.</p> <p>This option is necessary for each basicCAN 61 PLUS device.</p>
Net2Run IDE	<p>Software programming environment (Windows host) to build G-API based on-board UserCode programs for basicCAN 61 PLUS;</p> <p>includes: Net2Run IDE, QNX Neutrino CLT, G-API on-board libraries, single developer license</p>
UserCode Runtime	<p>UserCode runtime module for the execution of G-API based on-board UserCode programs on basicCAN 61 PLUS devices;</p> <p>This option is necessary for each basicCAN 61 PLUS device.</p>

4 Software

There are the following ways to integrate basicCAN 61 PLUS hardware in your own applications:

- [G-API Programming](#)
- [UserCode Programming](#)

4.1 G-API Programming

The G-API (GOPEL-API) is the C-based user interface for GOPEL electronic hardware under Windows®.

It provides a wide, hardware independent command set for CAN, LIN, K-Line, FlexRay, MOST, LVDS, ADIO and Diagnostic services.

No matter whether a PXI/ PCI, USB or Ethernet device is used, the commands remain the same.

The hardware abstraction introduced with the G-API gives the test application parallel access to the hardware, allowing one application to access multiple hardware interfaces; as well as multiple applications can access the same hardware interfaces in parallel.

Another feature introduced by the G-API is the asynchronous hardware access. This means no blocking execution for pending firmware commands. The command acknowledgement is provided via a callback mechanism.

With the HardwareExplorer (see also [Ethernet](#)) GOPEL electronic provides an effective hardware configuration and management tool, offering users an easy way to manage their hardware configurations and identifying specific hardware interfaces by logical names. Using logical interface names in the application saves from rebuilding the application when porting it to another interface or controller board, as the interface can be easily reassigned in the HardwareExplorer.

Furthermore, the HardwareExplorer provides a simple means of testing the interaction between hardware and software by executing the integrated self-tests.



Please consult the G-API documentation for further information. This documentation and the installation software are located in the *G-API* folder on the supplied "Product Information" CD.

4.2 UserCode Programming

basicCAN 61 PLUS devices can execute user programs direct on their PowerPC processor. This requires the UserCode run-time module being enabled.

The UserCode run-time module is an option for basicCAN 61 PLUS devices (plus other GOEPEL devices) and requires one license per unit.

Executing programs directly on the PowerPC improves the real-time performance remarkable and frees up PCI bandwidth on the host system.

Therefore GOEPEL electronic has ported and enhanced by additional on-board functionality their C-programming user interface called G-API from Windows® to the QNX Neutrino real-time operating system. The QNX Neutrino real-time operating system is based on a micro kernel architecture, providing clear separation between the kernel and each individual application.

This allows user applications to run in a separate virtual memory space, which ensures safe test execution and improves reliability.

The UserCode run-time module uses a superset of the G-API commands for Windows® ensuring an easy migration of existing program source code. Additional functions will provide access to event notifications, timer tasks, the FLASH file system and other RT OS resources as well as standard C libraries.

The PowerPC processor uses big-endian byte order which must be taken care of when writing or porting code for the UserCode run-time module.

For smooth migration from little to big-endian, a library of conversion macros is provided with the Net2Run IDE development system.

With the Net2Run IDE development system, GOEPEL electronic provides a complete tool chain for creating UserCode programs and for their direct execution on basicCAN 61 PLUS devices.

The Net2Run IDE development system is based on Eclipse IDE and contains the QNX Neutrino Command Line Tools (CLT), including PowerPC-Compiler, Linker and Debugger.

UserCode programs can be downloaded and debugged direct from Net2Run IDE via an Ethernet connection.

The figure below shows the Net2RunIDE development system:




Figure 4-1: Net2Run IDE Window



Please consult the G-API documentation for further information. This documentation and the installation software are located in the G-API folder of the supplied "Product Information" CD.

B

basicCAN 61 PLUS
 Addressing 3-17
 Basic Characteristics 3-2
 Basic variant 3-21
 Connections/LEDs 3-3
 Dimensions 3-2
 Driver Installation 2-3
 Ethernet 2-5
 Options 3-21
 Resources 3-1
 Status LEDs 3-4
 Supply 3-5

C

CAN Extension Board 3-8
 CAN Interfaces 3-6
 Computer interfaces 3-17

D

Digital IO 3-9
 Driver Installation
 USB 2-3

E

Ethernet 2-5, 3-17
 Extension
 FlexRay 3-7
 IO 3-11

F

FlexRay extension 3-7

G

G-API 4-2

H

HardwareExplorer 2-5, 4-2

I

IO Extension 3-11
 Type 1 3-11
 Type 2 3-14
 Isolation 3-17

P

Pinout
 Analog 3-19
 Digital 3-20
 Node 1..2 (4) 3-18
 Node 3..4 3-18
 Node A/ B 3-19
 Node B 3-18

S

Status LEDs 3-4
 Supply
 basicCAN 61 PLUS 3-5
 Test object 3-5

T

Test object
 Supply 3-5
 Transceivers 3-6

U

UserCode 3-22, 4-3